

Polyamide based particle foam Expand your ideas



Polyamide based particle foam with unique properties



- High heat deflection temperature
- High temperature resistance
- Excellent mechanical properties at temperature >120 °C
- Chemical resistance against automotive liquids

- Drop-in solution in EPP tooling (steam chest molding)
- Recyclability
- Simulation models available
- Processable via cathodic dip coating

Product	Bead size	Bulk density	
Ultramid® Expand D4S2925 UN	2.5 mm	290 g/L	Uncolored
Ultramid® Expand D4H2925 BK23381	2.5 mm	290 g/L	Heat stabilized
Ultramid® Expand Experimental D4H3510 BK23381	1.0 mm	350 g/L	Heat stabilized



Different bead sizes that fits for your requirements

Ultramid® Expand D4S2925 UN

Bead size: 2.5 mm





Ultramid® Expand D4S2925 BK23381

Bead size: 2.5 mm





Internal

Ultramid® Expand Experimental D4H3510 BK23381

Bead size: 1.0 mm







Ultramid® Expand Potential applications






Structural inserts



Heat deflection



Complex 3D shapes



Cell holder



Battery protection





Potential applications: Cell Holder Demonstrator











Demonstrator shows the versatility of Ultramid® Expand

- Different cell sizes
- Snap hooks
- Laser markable
- Threaded inserts
- Breakthroughs



Ultramid® Expand Production process








Cellular structure results in drastic weightreduction with high mechanical properties!





Superior mechanical properties at elevated temperature






- Ultramid® Expand shows significant advantages compared to EPP
- Excellent mechanical properties at high temperatures



Compressive strength (10%) after heat aging





Superior performance after heat aging



Ultramid® Expand Water uptake vs. shrinkage

Residual moisture content in % 0.0 2.0 4.0 6.0 8.0 10.0 12.0 14.0 16.0 0.0 Moisture content after foaming Shrinkage length / width - % 1.0 2.0 Drying / De-moisturizing 3.0 4.0 — ULT.EPA D4S2925 UN — ULT.EPA D4H3510 BK23381 5.0 Equilibrium



- 340 g/L sheets (300 mm x 200 mm x 25 mm)
- Drying at 80 °C after min. two days storage time



moisture content

Ultramid® ExpandOvermolding










- Overmolding with PA-GF
- Single-material recyclability
- Parts with undercuts possible
- GID/WID parts replacement potential












Full Ultrasim® CAE support available including particle filling simulation

Particle filling simulation


- Achieve best packing by optimizing:
 - Filler location, mold orientation, venting
- Coupled computational fluid and particle dynamics:
 - Predict fluid flow, particle trajectories
- Defect prediction:
 - Voids, packing inhomogeneities





Structural simulation

- Elastomeric foam model in Ultrasim[®] accounts for compressibility up to large deformations
- Perform virtual part testing and optimization
- Force-displacement curves for structural load cases
- Ultrasim® material cards available for different densities







Contact data

■ Project leader contact for Ultramid® Expand particle foam:

Dr. Patrick Spies

Mobile: +49 173 3479970

patrick.spies@basf.com

Industry contact for Ultramid® Expand particle foam:

Dennis Jopp

Mobile: +49 172 7440205

dennis.jopp@basf.com

Simulation contact for Ultramid® Expand particle foam:

Andreas Wüst

Phone: +49 172 7470859

andreas.wuest@basf.com





We create chemistry

Product disclaimer

- The data contained in this document as well as advice or other support services are based on our current knowledge and experience and are provided according to our best knowledge.
- In view of the many factors that may affect processing and application of our product, these data do not relieve processors from carrying out their own investigations and tests; neither do these data imply any guarantee of certain properties, nor the suitability of the product for customer's specific purpose.
- Any descriptions, drawings, photographs, data, proportions, weights etc. given herein may change without prior information and do not constitute the agreed contractual quality of the product.
- It is the responsibility of the recipient of our products to ensure that any proprietary rights and existing laws and legislation are observed.

